

BOSSTAB Touch Evo Floor Stand


Getting started guide




1. Feed cable up through the hinge pole. Ensure enough length is fed through to easily plug into your tablet.




2. Slide the hinge pole onto the base pole while feeding the cable through. Screw in (A) grub screws to secure.



3. Screw on baseplate with (B) screws with the charging cable running underneath.




4. Locate the Touch case and unscrew the (C) security screw to remove the top bracket that holds the adhesive.




5. Attach the Touch case to the hinge and screw in the (D) screws to secure.



6. Peel off the adhesive paper from the top bracket.




7. Place the bracket in the center of the tablet and press down and hold for 20 seconds.



8. Re-attach top bracket and secure with the security screw.



9. Plug in the charging cable.



Landscape Rotation Lock

Place case on the pole in a landscape position and screw (E) lock screw as shown to lock in place.



Portrait Rotation Lock

Place case on the pole in a portrait position and screw (E) lock screw as shown to lock in place.



Tilt Adjustment Lock

Using Allen key provided, tighten screw at desired angle to lock in position.